



Bend and remove the end of perforated backing card to improve ease of application.



Remove strip from card using sterile forceps or gloved hand.



Place the first strip centrally to align the wound, 90 degrees to the wound direction.



Anchor one end of the strip and approximate the wound edges. Fixate the strip across the wound and apply gentle pressure to ensure adhesion.



Apply the strips approximately 3mm apart.